





ALIGATOR



Aligator Watch AMOLED

Instructions for use

Basic layout of screens



Aligator
Watch AMOLED

Table of Contents

Important instructions	2
Controls and strap fitting	4
Wearing a watch correctly.....	4
Charging	5
Switching on and off	5
Control basics	5
Always ON Display.....	6
Menu of functions	8
Useful features	12
Information screens	13
Connecting your watch to your phone	15
Display measured data on your phone	24
Watch settings	25
Setting notifications on your watch	25
Phone and music functions in the watch.....	25
Setting the look of the dial	28
Record your workout on your watch or in the app.....	30
Add sports modes to your watch	31
Edit personal settings and data	31
Find your phone with your watch and vice versa	32
Waterproof IP67	32
Troubleshooting	33
Safety and ecology	34
Declaration of conformity.....	35

Thank you for purchasing an ALIGATOR product. Please read these instructions on how to use your new smartwatch.

Important instructions

- Handle the product and accessories with care and protect them from mechanical damage and dirt.
- Protect the product and accessories from extreme temperatures.
- Do not throw the product into fire or expose it to temperatures above +60°C. The product contains a built-in battery.
- Protect the product and accessories from falling to the ground.
- The product does not contain any user-repairable parts, never disassemble the product or accessories.
- Switch the product off on the aircraft unless specifically permitted to use it.
- Do not use the product near explosives.
- Keep out of reach of children and do not allow them to play with the product. It may contain small parts that could choke them or otherwise injure them.
- The software and hardware of the product is continuously upgraded. The manufacturer therefore reserves the right to change the instructions and individual functions of the phone without prior notice.



For more information, tutorials and video tutorials on how to set up your smartwatch, visit:
<http://www.aligator.cz/awamoled>




Controls and strap fitting




The watch is controlled by a touch screen ② and a button ① on the side.

The strap of the watch can be easily put on or taken off using the lever located on each of the lugs on the underside of the strap. Push the lever ③ and the spring bar will release.




Wearing a watch correctly

Put the watch on your wrist so that the back with the sensors fits snugly against the surface of your hand, see Fig.



Charging

Charge the watch before using it for the first time. To charge, use the included magnetic adapter, which is attached to the contacts on the back of the watch. The magnets will hold the end of the adapter in the correct position. Plug the other end of the adapter into a suitable USB socket. The display will indicate that the battery is charging when connected.



Turning on and off

To turn the watch on/off, press and hold button ① until the watch turns on/off. You will still need to press the button on the phone display to confirm that it has been switched off.

Control Fundamentals

The watch display is dimmed as standard to save battery power. To activate the watch display, press the button. The display will darken itself after a short period of time or you can darken it by pressing button ①.


Always ON Display

Always ON Display is a feature of the Aligator Watch Amoled that allows you to view information on the display even when the watch is asleep. You can choose from two types of time display – analogue or digital.

This mode is automatically turned off and can be conveniently turned on in the settings in the chapter – Dial. To save battery, the display is completely dimmed after 5 minutes if the watch does not detect any movement.

To view the function menu

Diagram of the basic dial layout




The menu of functions can be accessed by sliding your finger across the display from left to right (the opposite movement takes you back). The bubble menu is displayed by default. To select the selected function, tap the appropriate icon in the menu. Menu style can be toggled in settings. The watch offers 5 styles of menu display. (Settings → MENU STYLE). **By sliding your finger across the display from right to left**, you can scroll through the screens of individual functions and measured values.

To go back one level up in the menu, either press the button ① or swipe the display from left to right.


To quickly view messages, swipe up from the bottom of the home screen (swipe from left to right to go back).






For quick settings and overview, swipe from top to bottom on the main screen (opposite to go back). You can quickly switch watch modes, set brightness, vibration, activate silent mode or start settings. Connection and battery status information will also be displayed.















Feature menu


By swiping the display from left to right, you can select from the menu of the following functions:





Phone 	The dial pad is used to manually enter the phone number for the call.
Favorite contacts 	List of favorite contacts to call from the watch. It is set using an application on the phone.
Call records 	Displays a list of recent calls – tap to call the selected number/name again.
Voice assistant 	If the function is activated using the watch, it allows you to start the voice assistant on the phone by tapping the icon.
Daily activity 	It displays a daily overview of the number of steps taken, calories burned and distance traveled.

<p>Sports</p> 	<p>Measurement of training activity. A variety of sports and activities are available. This menu can be expanded using the application, where you choose the desired sport or activity and add it to the watch (more in the “Adding sports modes to the watch” chapter). After starting the training, the measurement can be paused/ended by moving the screen from left to right and pressing the button.</p>
<p>Sports records</p> 	<p>History of sports activity.</p>
<p>Pulse</p> 	<p>Heart rate – the sensor on the back of the watch is used for measurement, it is necessary that the watch is correctly placed on the wrist. The value is indicative, cannot be used for medical purposes.</p>
<p>Sleep</p> 	<p>Shows information and statistics about sleep duration and quality.</p>
<p>Blood pressure</p> 	<p>Estimated blood pressure – experimental function, the measured value may not correspond to reality and cannot be guaranteed in any way, an approximation from the heart rate sensor is used for the measurement. Cannot be used for medical purposes.</p>


<p>Blood oxygenation</p> 	<p>Display of blood oxygenation – experimental function, the measured value may not correspond to reality and cannot be guaranteed in any way, approximation from the heart rate sensor is used for measurement. Cannot be used for medical purposes.</p>
<p>Messages</p> 	<p>History of recent messages received.</p>
<p>Weather</p> 	<p>Current weather information.</p>
<p>Woman</p> 	<p>Displays the current overview of a woman's physiological cycles. Menstrual cycle, ovulation cycle, etc. The function is turned on in the application on the phone.</p>
<p>Music</p> 	<p>Allows you to remotely control the music player on your phone. When the watch phone function is active, the audio of the song will be played directly from the watch's built-in speaker.</p>
<p>Relax</p> 	<p>Function of breathing (relaxation) exercise.</p>
<p>Stopwatch</p> 	<p>Simple stopwatches.</p>




<p>Timer</p> 	<p>Simple timer (minute).</p>
<p>Alarm clock</p> 	<p>Possibility to set several alarms. The settings are in the app and you can turn the alarm on/off in the watch.</p>
<p>Wallet</p> 	<p>Adding a QR code for incoming payments.</p>
<p>Business card</p> 	<p>Allows you to upload a QR business card for social networks and other communication platforms using the application (Device tab → Business card).</p>
<p>Time setting</p> 	<p>Possibility to set the time and date directly in the watch.</p>
<p>Find phone</p> 	<p>After activation, it will start a sound or vibration in the put away phone, making it easier to find it.</p>
<p>Calculator</p> 	<p>A simple calculator.</p>
<p>Calendar</p> 	<p>A simple calendar.</p>






<p>Camera</p> 	<p>Allows you to remotely control the camera shutter on your phone. Requires running the app on your phone.</p>
<p>Settings</p> 	<p>Settings and useful functions.</p>

Useful Features

In the function menu, select **Settings** and choose one of the useful functions:




<p>Menu style</p> 	<p>The watch offers 5 menu display styles. Choose the one that suits you.</p>
<p>Dial</p> 	<p>It offers changing the watch face from 4 presets, setting the brightness, setting the backlight time, activating the backlight with your wrist or setting the Always on display, see chapter Always ON Display.</p>
<p>Battery</p> 	<p>Displays the current battery charge status and the option to activate the power saving mode.</p>

<p>Vibration and Sound</p> 	<p>Watch mode settings – mute, vibrate or vibrate and sound + vibration intensity.</p>
<p>Language</p> 	<p>Selection of the language mutation of the watch from dozens of options.</p>
<p>QR code</p> 	<p>It will display a QR code to download the app.</p>
<p>Time setting</p> 	<p>Possibility to set the time and date directly in the watch.</p>
<p>System</p> 	<p>System information, option to turn off, restart and reset the watch.</p>

Information screens

When you swipe the screen from right to left, the information screens for the watch functions will gradually appear:



<p>DAILY ACTIVITY</p> 	<p>Displays a daily summary of steps walked, calories burned and distance walked. Scroll up from the bottom to view the last 7 days.</p>
<p>PULSE</p> 	<p>Starts measuring the current heart rate. Scroll up from the bottom to see the measurements throughout the day and the average heart rate.</p>
<p>SLEEP</p> 	<p>Information and statistics on sleep duration and quality. Scroll up from the bottom to see the values for the last 7 days.</p>
<p>WEATHER</p> 	<p>Displays weather information.</p>
<p>PLAYER</p> 	<p>Allows you to remotely control the music player on your phone.</p>
<p>SPORTS</p> 	<p>View the list of sports downloaded on your watch.</p>

The order of the information screens can be changed or switched off on the last tab. Tap on the “+” icon to display the menu.

Connecting your watch to your phone

For full functionality, you need to connect the smartwatch wirelessly to the app on your phone. Download and install the **Fit Cloud Pro** app on your phone:



Attention! After installation and the first run, you will need to enable all the permissions that you will be asked for several times, otherwise the application will not work properly.

If you do not wish to register, press **“Login as guest”** at the top of the screen. Next, fill in your profile and continue by clicking **“Next”**.

On the next page, fill in your daily goal for steps walked and press **“Next”**.

If the background activity permissions page appears, continue with the confirmation button.



Welcome

FitCloudPro

"FitCloudPro" is an application for recording and analyzing user movement and health data. During the use of this application, you need to call your partial permissions and collect some of the upload devices and individual information. Please read the [FitCloudPro Privacy Policy](#) & [FitCloudPro User Agreement](#) carefully. Click "Agree" to indicate that you agree.

CANCEL

AGREE

Profile

Fill in your personal information and collect data more accurately



Nickname

FitCloudPro

11/48

Birthday >

Sex >

Height >

Weight >

NEXT

Use Without Account



FitCloudPro



Mobile Phone/Email



Password



[Forget password?](#)

LOGIN

[NO ACCOUNT? TO CREATE](#)

Bind Device



SKIP

Search

Following permissions are required

Do you want to request for the next step?

- Nearby devices**
Used to search/connect nearby devices

CANCEL

OK



^ Other devices

Bind Device

SKIP

Aligator Amoled
70:A1:E1:0A:F4:D9-59 

Connect

Search

Make sure the watch is fully charged

Keep the watch and the mobile phone within 0.5 meters

Search for places with few Bluetooth devices

Make sure the watch is not bonded or connected by another phone



^ Other devices

Bind Device 

SKIP



Allow **FitCloudPro** to
find, connect to, and
determine the relative
position of nearby
devices?

Allow

Don't allow



^ Other devices

Bind Device 

SKIP

Aligator Amoled

70:A1:E1:0A:F4:D9

-54 

Connect

Search

Aligator Amoled

70:A1:E1:0A:F4:D9



Connecting



Make sure the watch is fully charged

Keep the watch and the mobile phone within 0.5 meters

Unable to connect?

CANCEL BIND



^ Other devices

Device

Aligator Amoled

Connected



Manage Audio Bluetooth



Connected



Auto Connect Audio



1

2

1. Whether to automatically connect audio Bluetooth every time the watch is connected

2. Audio Bluetooth status, manually set connection or disconnection

I KNOW

Dial library



Home



Device



Me

Connect your watch to your phone:

1. The app will prompt you for permission to find nearby devices, press **“Allow”**.
2. Bring the watch close to your phone and the app will list the devices found.
3. Select **Aligator Amoled** and tap **“Connect”**.
4. You will need to confirm this connection on your watch.
5. The watch is paired.
6. Here you will need to allow the application the permissions it will request, otherwise it will not work properly. Done.

Display measured data on your phone

Once your watch is paired with your phone, launch the **Fit Cloud Pro** app and press the **“Home”** icon at the bottom of the app screen. You will now see the information downloaded from the watch – step count, heart rate, blood pressure, blood oxygenation, distance, calories and more.

You can also view records going back over the previous days or month.

Note: data is continuously downloaded from the watch via a wireless connection, but the watch must be within range of the phone – a few metres.

Watch settings

The watch is set up using the **Fit Cloud Pro** app on your phone. Tap the “**Devices**” icon at the bottom of the app screen.

Now you can make all the settings of the watch, (changing the appearance of the face, alarms, notifications and many other functions).

Setting notifications on your watch

An important function of the watch is notification of incoming calls, SMS messages, social network messages and notifications from other apps.

1. On the “**Devices**” tab, select **Alerts**.
2. A selection of your favourite apps will appear, tap the toggle next to the name to activate notifications for that app.
3. You may be asked to allow access to notifications the first time you set it up.

Phone and music functions in the watch

Thanks to the built-in microphone and speaker, the watch allows you to make phone calls and listen to music. When activated, it acts as an advanced handsfree headset, allowing you to answer and place calls and dial phone numbers and contacts directly on the watch.

ATTENTION! When you connect and activate the calling function, the music and audio playback from your phone and the voice assistant control are also redirected to the watch.

To activate and deactivate the telephoning function

The phone function on your watch will turn on automatically when you pair it. You can deactivate this feature in the quick overview.

1. Scroll down from the top of the screen to get a quick overview.
2. Tap the phone icon to see the extended menu.
3. The first switch is for turning the mobile phone function on/off in the watch.
4. The second switch is used to activate the built-in speaker.


ATTENTION! When the phone function is active, the battery life will be reduced.

Make calls and play music directly on your watch

- Tap the red icon to reject an incoming call, and the green icon to accept it.




- Tap the speaker icon to adjust the volume.
- The microphone can be switched on/off using the microphone icon.



If the phone call function is active, music and audio from your phone will be transferred to your watch. You can also use the remote control function on your mobile phone player with your watch to enjoy music directly on your watch thanks to the built-in speaker.

More features for making calls on your watch

1. Select **Telephone** from the features menu and you will see the dialpad, which is used to manually enter the phone number to call.



2. Next on the menu is **Favourite contacts** – a list of your favourite contacts for calling from your watch. It is set using the app on your phone.

To add favourite contacts in the app

1. Launch the **Fit Cloud Pro** app on your phone
2. Tap the **“Devices”** tab.
3. Select **Favourite Contacts**.

4. Press **Add** and select up to 10 contacts in your phonebook. You must **allow the app** to access your contacts to work properly.
5. After the selections, you can change your contacts as you wish.
6. Press **Edit**, select the contacts you want to remove from the list – or select **Select All** and then **Remove**.
7. The withdrawal still needs to be confirmed. Done.
8. The transfer to the watch is instantaneous.

Attention! The phone needs to be close to the watch to work properly. Depending on the environment, the range of the wireless connection can vary from units to low tens of meters.

Setting the look of the dial

Aligator Watch Amoled offers a wide range of watch face designs. Several looks are pre-installed directly in the watch. Dozens of additional looks are then available through the app, including the ability to set a custom photo or image directly on the watch face background.

Change the appearance of the watch face

1. Press your finger on the watch display until the current face becomes smaller.
2. Move your finger sideways to select from the available dials.

3. Confirm the selected dial by touching the screen.

*You can also change the dial in the menu: **Settings** → **Dial** → **Change dial** or by turning the button ① on the side of the watch.*

Select other dial designs in the app

1. On the “**Devices**” tab, select the “**Dials**” tab.
2. Wait for a while until all available dials are loaded (new dials are added gradually).
3. Tap the dial you want to use, then tap “**Use dial**” below the dial image.
4. The watch face will be downloaded and then installed. The procedure can be followed on the phone screen. The watch faces you have downloaded are then displayed in the “**My watch face**” tab.

Setting a custom image on the dial

1. On the “**Devices**” tab, select the “**Dials**” tab.
2. In this tab, tap the first dial.
3. Use the “+” button to set your own photo or image as the background of the watch face.
4. You can choose from 2 options, “**Take a photo**” or “**Select from album**”.

5. You can set the position of the time display or the font colour in the **“Colour and Position”** subfolders.
6. When you have finished setting up, press the **„Set as dial“** button and **“Confirm”** here.

Record your workout on your watch or in the app

As mentioned in the **Features section**, the watch allows you to record workouts for several sports.

However, you can also record your workout directly using the **Fit Cloud Pro** app on your phone. In this case, the watch only serves as a step and heart rate sensor and the workout will be recorded directly in the app, including the route obtained from the phone's GPS receiver.

To start a workout on your phone, press the running dummy icon in the **Fit Cloud Pro** app. The **“Sports”** tab will open. Several sports are available here. Activity logging is automatically started by tapping the selected sport, and the app stores the GPS route record and heart rate information measured by the watch. To end the workout or pause it, you need to hold the **“Pause”** button. After the protection period, you will have the choice to stop or resume the workouts, just tap on the desired action.

Adding sports modes to your watch

As mentioned in the **Features Menu chapter**, the watch allows you to add several additional sports modes directly to the watch.

1. In the **“Devices”** tab, select the **“Other Sports”** tab
2. Wait a moment for all available sports modes to load.
3. Tap the sport you want to upload to your watch, then press **“Confirm”**.
4. Sport mode will be downloaded to the watch. The progress can be monitored on the phone screen. You can check after the download in the **“Sport”** tab on the watch, where the new mode will be added to the end of the list.

Edit personal settings and data

To edit your personal information and change some of the app’s other settings, press the **“Profile”** icon at the bottom of the screen. You will now be able to set, for example, your weight, age and other information about you, as well as your daily goal.

Find your phone with your watch and vice versa

If the watch is connected to your phone, it can be easily located. Select “**Find phone**” from the watch’s function menu. You can then tap the icon on the watch screen to start playing audio on the watch.

If you’re looking for a watch, launch the **Fit Cloud Pro** app on your phone, go to the “**Devices**” tab and select “**Find a wristband**”. The watch will light up and vibrate.

Attention! Vibration must be enabled on the watch and the battery must not be discharged. Otherwise, the watch screen will only light up.

Waterproof IP67

The watch is designed to be water resistant to IP67 standard, however, we strongly recommend that you avoid contact with water as much as possible.

Microscopic cracks in the seal may occur during use due to shocks or wear on the case. In this case, water could enter the case and cause damage that is not covered by the warranty.

Never dive, bathe or shower with the watch – pressurised or hot water could penetrate the watch and cause damage not covered by the warranty.

Never press the button if the case is in contact with water, water ingress and damage could occur, which is not covered under warranty.

Troubleshooting

Notifications do not appear on the watch

Please make sure you have enabled **Fit Cloud Pro** to access notifications as described in this guide (see **Setting up notifications on your watch**).

Alternatively, open your phone's settings and type "access to notifications" in the search box and check that access is enabled for **Fit Cloud Pro**.

The watch does not connect

If you can't connect your watch to your phone, try turning Bluetooth off and on on your phone and restarting your phone. If the watch doesn't connect, try searching for it again in the app. If the watch does not connect, reset it – Settings → System → **Reset**. Then restart your phone and reconnect the watch in the app following the procedure in the **Connecting to your phone** chapter.

The watch cannot be charged with a power bank

The charging current of the watch is very small. Therefore, some power banks mistakenly evaluate the connected watch as a phone that is already charged and automatically switch off charging.

Safety and ecology



Built-in battery

The product contains a built-in single-cell lithium battery, which does not belong in normal municipal waste and may contain substances harmful to the environment! Once the product has reached the end of its life, the battery can be removed and handed over for further environmentally friendly treatment.

Instructions for safe removal of the battery

(By the user or a qualified professional independent of the dealer)

Make sure the battery is fully discharged (or let the watch fully discharge first). Use a knife or chisel to carefully peel off the back of the watch. Danger of injury! Disconnect or cut the leads to the battery one at a time with scissors to prevent short circuiting. Remove the battery carefully so as not to perforate or deform the battery – danger of electrolyte leakage, short circuit and shock! Observe the work safety regulations and use protective equipment or leave the task to a specialist!

Used electrical equipment

Never dispose of the product in normal municipal waste, it may contain substances hazardous to the environment! After use, it must be handed over to the appropriate collection point for recycling or environmentally friendly disposal. Check with your dealer or municipal office

where such a place is located or you can hand it over directly to the dealer or to one of the ADART COMPUTERS s.r.o. branches.

It is illegal to handle the product in contravention of these instructions!

Declaration of Conformity

ADART COMPUTERS s.r.o. hereby declares that the type of radio device Aligator Watch Amoled, L61D, complies with Directive 2014/53/EU.

The full text of the EU Declaration of Conformity is available on the following website:

www.aligator.cz



www.aligator.cz

Copyright ©
ADART COMPUTERS s.r.o.
Čimická 717/34, CZ-Prague

Aligator Watch AMOLED

with many great features on offer!

