



**ALIGATOR**




# Aligator Watch Lady X

Instructions for use

# Table of Contents



Important instructions.....	4
Controls and strap fitting .....	6
Wearing a watch correctly.....	6
Charging.....	7
Switching on and off.....	7
Control basics.....	7
Feature menu.....	10
Useful features.....	12
Information screens.....	13
Connecting your watch to your phone .....	15
Display measured data on your phone .....	16
Monitoring the physiological cycle .....	17
Watch settings.....	17
Setting notifications on your watch .....	18
Phone and music functions in the watch.....	18
Setting the look of the dial .....	22
Record your workout on your watch or in the app.....	24
Edit personal settings and data .....	24
Find your phone with your watch and vice versa.....	25
Waterproof IP67.....	25
Troubleshooting.....	26
Safety and ecology.....	27
Declaration of conformity.....	28

# Basic layout of screens



Aligator  
Watch Lady X

# Lots of useful features on offer



Thank you for purchasing an ALIGATOR product. Please read these instructions on how to use your new smartwatch.

## **Important instructions**


- Handle the product and accessories with care and protect them from mechanical damage and dirt.
- Protect the product and accessories from extreme temperatures.
- Do not throw the product into fire or expose it to temperatures above +60°C. The product contains a built-in battery.
- Protect the product and accessories from falling to the ground.
- The product does not contain any user-repairable parts, never disassemble the product or accessories.
- Switch the product off on the aircraft unless specifically authorised to use it.
- Do not use the product near explosives.
- Keep out of reach of children and do not allow them to play with the product. It may contain small parts that could choke them or otherwise injure them.
- The software and hardware of the product is continuously upgraded. The manufacturer therefore reserves the right to change the instructions and individual functions of the phone without prior notice.



For more information, tutorials  
and video tutorials on how to set  
up your smartwatch, visit:  
**[www.aligator.cz](http://www.aligator.cz)**



## Controls and strap fitting



The watch is equipped with two buttons on the side for basic easy operation.


The watch display is fully touch-sensitive, which is used to control other functions of the watch.

The watch strap can be easily removed by means of a lever located on each of the lugs on the underside of the strap. Push the lever ③ and the link will release.




## Wearing a watch correctly

Put the watch on your wrist so that the back with the sensors fits snugly against the surface of your hand, see Fig.



## Charging

Charge the watch before using it for the first time. To charge, use the included magnetic adapter, which is attached to the contacts on the back of the watch. The magnets will hold the end of the adapter in the correct position. Plug the other end of the adapter into a suitable USB socket. The display will show the battery charge status when connected.



## Switching on and off

To turn the watch on/off, press and hold button ① until the watch turns on/off. You will still need to press the button on the phone display to confirm that it has been switched off.

## Control basics


The watch display is dimmed as standard to save battery power. To activate the watch display, press the button. The display will darken itself after a short period of time or you can darken it by pressing button ①.



To view **the function menu**, slide your finger across the display from **left to right** (move backwards to go back). A circular menu is displayed by default. To select a function, tap on the corresponding icon in the menu and tap in the middle of the display to activate it. In the settings, the menu style can be switched to a classic line list (Settings → STYLE MENU).

**By sliding your finger across the display from right to left**, you can scroll through the individual function and measurement screens in sequence.

## Diagram of the basic layout of watch faces



**To go back up a level in the menu** either press button ①, or swipe the display from left to right.

**To quickly view messages,** swipe up from the bottom of the main screen (swipe back the other way to go back).


Swipe down from the top of the main screen **for quick setup and overview** (swipe back to go back). You can quickly switch watch modes, adjust brightness, vibration, or start settings. Connection, battery status and weather information are also displayed.





**Press button ②** to display the training activity measurement menu.










## Feature menu

Swipe the display from left to right to select from the following functions:




<b>Steps</b> 	Number of steps per day. It is always counted from midnight. The value is approximate and may differ from the number of steps actually walked.
<b>Sleep</b> 	Displays information and statistics on sleep duration and quality.
<b>Heart rate</b> 	Heart rate – the sensor on the back of the watch is used to measure it, it is necessary that the watch is correctly positioned on the wrist. The value is approximate, it cannot be used for medical purposes.
<b>Sports</b> 	Measuring training activity. A variety of sports and activities are available. Select an activity and tap to start. Once the workout has started, the measurement can be paused/stopped by scrolling the screen from left to right and pressing the button. You can also press button ② to quickly view the training activity.

<p><b>Phone</b></p> 	<p>Telephoning function. List of recent calls, dialer option and display of contacts synced with the watch.</p>
<p><b>Oxygenation</b></p> 	<p>Display of blood oxygenation – experimental function, the measured value may not correspond to reality and cannot be guaranteed in any way, an approximation from the heart rate sensor is used for the measurement. Cannot be used for medical purposes.</p>
<p><b>Weather</b></p> 	<p>Current weather information (only if your phone is connected). Swipe up from the bottom to see the forecast for the next 6 days.</p>
<p><b>Trigger</b></p> 	<p>Allows you to remotely control the camera shutter on your phone. Requires launching an application on the phone.</p>
<p><b>Player</b></p> 	<p>Allows you to remotely control the music player on your phone. If the phone function of the watch is activated, the sound of the song will be played directly from the built-in speaker in the watch.</p>




<p><b>Breathing</b></p> 	<p>Functions of breathing exercises</p>
<p><b>Settings</b></p> 	<p>Settings and useful features. You can set the calling function, brightness, vibration, menu style, view technical information, reset data, etc. Also includes other functions (stopwatch, timer and more).</p>

## Useful features

Select **Settings** from the features menu and choose one of the useful features:



<p><b>Game</b></p> 	<p>A game to pass the time</p>
<p><b>Stopwatch</b></p> 	<p>Simple stopwatch</p>
<p><b>Alarm clock</b></p> 	<p>Possibility to set several alarms directly in the watch</p>

<p><b>Timer</b></p> 	<p>Simple timer (minute)</p>
<p><b>Application</b></p> 	<p>Displays a QR code to easily download the watch app to your phone.</p>
<p><b>Phone search</b></p> 	<p>When activated, triggers sound on the phone in the snooze mode, making it easier to find the phone.</p>

## Information screens

When you swipe the screen from right to left, the information screens for the watch functions will gradually appear:



<p><b>TODAY</b></p> 	<p>Displays the number of steps, last sleep time, and time of training activity. Tap each value to view detailed information.</p>
<p><b>HEALTH</b></p> 	<p>Displays your last heartbeat and blood oxygenation. Tap each value to start a new measurement.</p>
<p><b>TIME</b></p> 	<p>Displays weather information. Scroll up from the bottom to view the forecast for the next 6 days.</p>
<p><b>SPOUSE</b></p> 	<p>Allows you to remotely control the camera shutter on your phone. Requires launching an app on the phone.</p>
<p><b>THE PLAYER</b></p> 	<p>Allows you to remotely control the music player on your phone.</p>
<p><b>BREATHING</b></p> 	<p>Functions of breathing exercises</p>
<p><b>PHONE</b></p> 	<p>If the watch phone function is activated, the phone controls (<b>call history, dial pad and contacts</b>) are displayed.</p>

## Connecting your watch to your phone

For full functionality, you need to connect the smartwatch wirelessly to the app on your phone. Download and install the **Da Fit** app on your phone:



***Attention! After installation and the first run, you will need to enable all the permissions that you will be asked for several times, otherwise the application will not work properly.***

Once all permissions are enabled, the profile page opens. Enter your details – gender, height, age, etc. Finish the settings by clicking the button below with the „confirm“ icon.

(For more accurate records and calculation of values, we recommend that you enter your information according to reality.)



## Connect your watch to your phone:

1. In the app, go to the watch settings screen by tapping the icon in the middle of the bottom of the screen.
2. Hold the watch close to your phone and press the „**Add device**“ button.
3. The app displays a list of the devices found.
4. Tap to select the **Alligator Lady X**.
5. The watch is paired. Done!

## Display measured data on your phone

Once your watch is paired with your phone, launch the **Da Fit** app and press the first icon from the left at the bottom of the app screen.

The „**Today**“ screen appears with information downloaded from the watch – step count, sleep, heart rate, blood oxygenation, training activity log and more. By tapping on the tab of any of the measured variables, you can also view records going back over previous days, or select the date you want to find out information about from the calendar.

***Note: data is continuously downloaded from the watch via a wireless connection, but the watch must be within range of the phone – a few metres.***

## Monitoring the physiological cycle

For monitoring the physiological cycle, menstruation and ovulation periods, etc. Follow these steps:

1. In the app, tap the middle icon at the bottom of the screen, then select „**Other**“.
2. At the bottom of the menu displayed, you can turn „**Physiological Cycle Reminder**“ on or off.
3. When the function is enabled, additional setting parameters will be displayed and reminders will be displayed in the watch.

## Watch settings

The watch is set up using the **Da Fit** app on your phone. At the bottom of the app screen, tap the middle icon with the watch symbol.

Now you can make all the settings of the watch, (change the appearance of the face, alarms, notifications and many other functions).

## Setting notifications on your watch

An important function of the watch is notification of incoming calls, SMS messages, social network messages and notifications from other apps.

1. Go to the device screen by tapping the middle icon at the bottom of the app.
2. Select **Notifications**.
3. A selection of alerts will appear, which you can activate by tapping the toggle next to the name.
4. When turning on notifications, the application will ask for different access permissions – you must **allow** access for it to work properly. The first time you set it up, you will also see a screen to allow access to notifications. Turn on the toggle next to the **Da Fit** app.

## Phone and music functions in the watch

Thanks to the built-in microphone and speaker, the watch allows you to make phone calls and listen to music. When activated, it acts as an advanced hands-free headset, allowing you to answer and place calls and dial phone numbers and contacts directly on the watch.

***ATTENTION! When you connect and activate the calling function, the music and audio playback from your phone and the voice assistant control is also redirected to the watch.***

## **To activate and deactivate the telephoning function**

In order to use the phone feature on your watch, you must first enable it on your watch and then pair your phone to your watch using the dual wireless audio connection.

- 1.** On your watch, go to **Settings** in the features menu, then tap **Phone** to display it: **On** – the phone icon turns green.
- 2.** On your mobile phone, in the Bluetooth settings, select **Pair new device** and search for **Audio\_LadyX\_...**
- 3.** Connect to this device.
- 4.** The phone function of the watch is paired. Done!

**To deactivate** the phone feature on your watch, open **Settings**, then tap **Phone** to display it: **Off**. – The icon turns grey. To permanently deactivate the feature, in the Bluetooth settings on your phone, delete **Audio\_LadyX\_...** from the list of paired devices.

***ATTENTION! When the phone function is active, the battery life will be reduced.***

## Make calls and play music directly on your watch

- Tap the red icon to reject an incoming call, and the green icon to accept it.



- Tap the phone icon to switch the phone call between your watch and phone.

- Tap the speaker icon to adjust the volume.

- The microphone can be switched on/off using the microphone icon.



If the phone call function is active, music and audio from your phone will be transferred to your watch. You can also use the remote control function of the player on your mobile phone with the watch and enjoy music directly on the watch thanks to the built-in 3W speaker.

## More features to make calls on your watch

1. Select **Phone** from the features menu.
2. The telephony menu will appear:



- **History** – displays a list of recent calls – tap to call the selected number/name again.
- **Dialpad** – used to manually enter a phone number for a call.
- **Contacts** – a list of your favourite contacts to call from your watch. Set up using the app on your phone.

***Note: If the calling feature is active, only the names in your favourites list will be displayed for incoming calls. Otherwise, only the phone number will be displayed.***

## **To add favourite contacts in the app**

1. Launch the **Da Fit** app on your phone.
2. Go to the watch settings screen by tapping the middle icon at the bottom of the app.
3. Select **Favourite Contacts**.
4. Press **Add** and select up to 8 contacts in your phonebook. You must **allow** the app to access your contacts to work properly.
5. After selecting your contacts, press **Confirm**, first in the top right corner and then on the main screen.
6. Contact transfer will be initiated.
7. Completion of the transfer is indicated in the application.

***Attention! The phone needs to be close to the watch to work properly. Depending on the environment, the range of the wireless connection can vary from units to low tens of meters.***

## **Setting the look of the dial**

The **Aligator Watch Lady X** offers a wide range of watch face designs. Several looks are pre-installed directly in the watch. Dozens of additional looks are then available through the app, including the ability to set a custom photo or image directly on the watch face background.

### **Change the appearance of the watch face**

1. Press your finger on the watch display until the current face becomes smaller.
2. Move your finger sideways to select from the available dials.
3. Confirm the selected dial by touching the screen.

### **Select other dial designs in the app**

1. Go to the device screen by tapping the middle icon at the bottom of the app and selecting **Clocks**.

2. The dials installed in the watch will be displayed.
3. At the bottom of the screen, select **More dials**. Wait a moment for all available dials to load (new dials are added gradually).
4. Tap the dial you want to use, then tap the „**Download**“ button below the dial
5. The watch face can be downloaded and then installed. The procedure can be followed on the phone screen.

## **Setting a custom image on the dial**

1. Go to the device screen by tapping the middle icon at the bottom of the app and selecting **Clocks**.
2. Select the 5th dial and tap the „**Edit**“ button next to it.
3. You can set your own photo or image as the background of the dial with the „**Select Image**“ button
4. You can also set your own font colour and placement of information on the screen.
5. Press the „**Save**“ button on the top right to save your changes and upload your own watch face.



## Record your workout on your watch or in the app

As mentioned in the **Features** chapter, the watch allows you to record workouts for several sports.

However, you can also record your workout directly using the **Da Fit** app on your phone. In this case, the watch only serves as a step and heart rate sensor and the workout will be recorded directly in the app, including the route obtained from the phone's GPS receiver.

To start a workout on your phone, press the first icon on the bottom left of the screen in the **Da Fit** app to go to the **Today** screen. Tap the **Outdoor Running** tab and press the **Start** button. The workout recording on your phone will start.

After the training is completed, the training data is saved and you can view the route on the map and other information in the calendar.

## Edit personal settings and data

To edit your personal information and change some of the app's other settings, press the icon at the bottom right of the screen – the **My Profile** screen will appear.

You will now be able to set your weight, age and other information about yourself, as well as a daily goal.

## Find your phone with your watch and vice versa

If your watch is connected to your phone, it can be easily located. Select **Settings** → **Phone search** from the watch's features menu. You can then tap the icon on the watch screen to start playing audio on the watch.

If you're looking for a watch, launch the **Da Fit** app on your phone, go to the watch settings screen (middle icon at the bottom) and select **Other** → **Find a device**. The watch will light up and vibrate.

***Caution! Vibration must be enabled on the watch and the battery must not be low. Otherwise, the watch screen will only light up.***

## Waterproof IP67

The watch is designed to be water resistant to IP67 standard, however, we strongly recommend that you avoid contact with water as much as possible.

Microscopic cracks in the seal may occur during use due to shocks or wear on the case. In this case, water could enter the case and cause damage that is not covered by the warranty.

Never dive, bathe or shower with the watch – pressurised or hot water could penetrate the watch and cause damage not covered by the warranty.

Never press the button if the case is in contact with water, water ingress and damage could occur, which is not covered under warranty.

## Troubleshooting

### Notifications do not appear on the watch

Please make sure you have enabled the **Da Fit** app to access notifications as described in this guide (see **Setting notifications on your watch**).

Alternatively, open your phone's settings and enter „access to notifications“ in the search box and check that access is enabled for **Da Fit**.

### The watch does not connect

If you can't connect your watch to your phone, try turning Bluetooth off and on on your phone and restarting your phone. If the watch doesn't connect, try searching for it again in the app. If your watch doesn't connect, reset it – in your watch, swipe down from the top, tap the „**Settings**“ icon and select „**Reset**“.

Then restart your phone and reconnect your watch in the app, following the steps in the **Connecting to your phone** section.

### The watch cannot be charged with a power bank

The charging current of the watch is very small. Therefore, some power banks mistakenly evaluate the connected watch as a phone that is already charged and automatically switch off charging.

## **Safety and ecology**



### **Built-in battery**

The product contains a built-in single-cell lithium battery, which does not belong in normal municipal waste and may contain substances harmful to the environment! Once the product has reached the end of its life, the battery can be removed and handed over for further environmentally friendly treatment.

### **Instructions for safe removal of the battery**

**(By the user or a qualified professional independent of the dealer)**

Make sure the battery is fully discharged (or let the watch fully discharge first). Use a knife or chisel to carefully peel off the back of the watch. Danger of injury! Disconnect or cut the leads to the battery one at a time with scissors to prevent short circuiting. Remove the battery carefully so as not to perforate or deform the battery – danger of electrolyte leakage, short circuit and shock! Observe the work safety regulations and use protective equipment or leave the task to a specialist!

### **Used electrical equipment**

Never dispose of the product in normal municipal waste, it may contain substances hazardous to the environment! After use, it must be handed over to the appropriate collection point for recycling or environmentally friendly disposal. Check with your dealer or municipal office

where such a place is located or you can hand it over directly to the dealer or to one of the ADART COMPUTERS s.r.o. branches.

It is illegal to handle the product in contravention of these instructions!

## **Declaration of Conformity**

ADART COMPUTERS s.r.o. hereby declares that the type of radio device Aligator Watch Lady X, NK28, complies with Directive 2014/53/EU.

The full text of the EU Declaration of Conformity is available on the following website:

**[www.aligator.cz](http://www.aligator.cz)**



**[www.aligator.cz](http://www.aligator.cz)**

Copyright ©  
ADART COMPUTERS s.r.o.  
Čimická 717/34, CZ-Prague